User Manual

TAB 4G T701

Before operating the unit please read through this manual

Contents

Using your TAB 4G T701 1

Getting started 1

Charging your TAB 4G T701 1

Turning on your TAB 4G T701 1

Gestures for the TAB 4G T701 2

Touch screen gestures for Windows® 8.1 2

Working 7

Starting for the first time 7

Windows® 8.1 lock screen 7

Windows® UI 8

Start screen 8

Windows® Apps 8

Start button 9

Context menu 10

Customizing your Start screen 11

Working with windows® apps 12

Accessing the Apps screen 13

Charms bar 14

Snap feature 16

Wi-Fi 17

Bluetooth 18

Turning your TAB 4G T701 off 20

Putting your TAB 4G T701 to sleep 20

Recovering 21

Refreshing your TAB 4G T701 21

Restoring your TAB 4G T701 22

Using your TAB 4G T701

Getting started

Charging your TAB 4G T701

A. Connect the DC cable to the power adapter.
B. Plug the DC connector into DC port of your TAB 4G T701

C. Plug the power adapter into a grounded power outlet.
D. Charge the TAB 4G T701 for eight (8) hours before using it in battery mode for the first time.

> **NOTE:** The power adapter may vary in appearance, depending on your country or region.

Turning on your TAB 4G T701

Press the power button.



Gestures for the TAB 4G T701

Gestures allow you to launch programs and access the settings of your TAB 4G T701. Refer to the following illustrations when using hand gestures on your TAB 4G T701.

Touch screen gestures for Windows® 8.1

Left edge swipe

Swipe from the left edge of the screen to shuffle your running apps.

Right edge swipe

Swipe from the right edge of the screen to launch the Charms bar.

Tap/Double tap

- Tap an app to launch it.
- On Desktop mode, Double-tap an application to launch it.

Tap and hold

- To move an app, tap and hold the app tile then drag it to a new location.
- To close an app, tap and hold the top side of a running app and drag it down to the bottom of the screen.

Zoom out



Bring together your two fingers on the touch screen panel.

Zoom in

Spread apart your two fingers on the touch screen panel.

Top edge swipe

In the Start screen, swipe from the top edge of the screen to view the Customize bar.

In a running app, swipe from the top edge of the screen to view its menu.

Finger slide

Slide your finger to scroll up and down and slide your finger to pan the screen left or right.

Swipe up



Swipe up from the Start screen to launch the Apps screen.

Swipe down



Swipe down from the Apps screen to return to the Start screen.

Working

Starting for the first time

When you start your computer for the first time, a series of screens appear to guide you in configuring the basic settings of your Windows® 8.1 operating system.

To start your TAB 4G T701 for the first time:

1. Press the power button on your Table. Wait for a few minutes until the setup screen appears.
2. From the setup screen, pick a language to use on your TAB 4G T701. As other settings appear, select your country or region, app language, keyboard layout, and time zone then tap **Next**.
3. Carefully read the License Terms, and then tap **I Accept.**
4. Follow the onscreen instructions to configure the following basic items:
   - Personalize
   - Connect
   - Settings
   - Your account
5. After configuring the basic items, the Windows®8.1 tutorial appears. Watch this to learn more about Windows®8.1 functionalities.

Windows® 8.1 lock screen

The Windows®8.1 lock screen may appear when your TAB 4G T701 enters the Windows®8.1 operating system. To proceed, swipe up the lock screen on your TAB 4G T701 to go to the Start screen

Windows® UI

Windows® 8.1 comes with a tile-based user interface (UI) which allows you to organize and easily access Windows® apps from the Start screen. It also includes the following features that you can use while working on your TAB 4G T701.

Start screen

The Start screen appears after successfully signing in to your user account. It helps organize all the applications you need in just one place.

Windows® Apps

These are apps pinned on the Start screen and displayed on tiled-format for easy access.

> **NOTE:** Some apps require signing in to your Microsoft account before they are fully launched.

Windows apps

Start button

Windows® 8.1 features the Start button that allows you to switch between the two most recent apps that you opened.

To use the Start button, tap Desktop app then tap 



Context menu

The context menu appears as a box filled with quick-access to some of the programs inside Windows® 8.1 when you tap and hold the Start button.

The context menu also includes the following shutdown options for your TAB 4G T701: Sign out, Sleep, Shut down, and Restart.



Customizing your Start screen

Windows® 8.1 also enables you to customize your Start screen, allowing you to boot directly to the Desktop mode and customize the arrangement of your apps onscreen.

To customize the settings of your Start screen:

1. Launch the Desktop.
2. Tap and hold anywhere on the taskbar except on the Start button, then tap **Properties** to launch the **Taskbar and Navigation properties** window.
3. Select the **Navigation** tab then tick the options you want to use.


Taskbar and Navigation properties
Taskbar
Navigation
Jump Lists
Toolbars
Corner navigation
When I point to the upper-right corner, show the charms
When I click the upper-left corner, switch between my recent apps
Replace Command Prompt with Windows PowerShell in the menu when I right-click the lower-left corner or press Windows key+X
Start screen
When I sign in or close all apps on a screen, go to the desktop instead of Start
Show my desktop background on Start
Show Start on the display I'm using when I press the Windows logo key
Show the Apps view automatically when I go to Start
Search everywhere instead of just my apps when I search from the Apps view
List desktop apps first in the Apps view when it's sorted by category
OK
Cancel
Apply

4. Tap **Apply** to save the new settings then tap **OK**.

Working with windows® apps

Use your TAB 4G T701's touch screen panel to launch, customize, and close apps.

Launching apps

Tap an app to launch it.

Customizing apps

You can move, resize, unpin, or close apps from the Start screen using the following steps:

Moving apps

Tap and hold the app tile then drag it to a new location.

Resizing apps

To resize an app:

1. Tap and hold the app tile for one (1) second, then release it to launch the **Customize** bar.
2. Tap 

d select an app tile size.

Unpinning apps

To unpin an app:

1. Tap and hold the app tile for one (1) second, then release it to launch the **Customize** bar.
2. Tap 

to unpin an app.

Closing apps

Tap and hold the top side of the running app then drags it down to the bottom of the screen to close it.

Accessing the Apps screen

Aside from the apps already pinned on your Start screen, you can also open other applications through the Apps screen.



Launching the Apps screen

Swipe the Start screen up to launch the Apps screen.

Pinning more apps on the Start screen

To pin an app on the Start screen:

1. Tap and hold the app tile for one (1) second, then release it to launch the **Customize** bar.
2. Tap 

to pin the selected app on the Start screen.

Charms bar

The Charms bar is a toolbar that can be triggered on the right side of your screen. It consists of several charms that allow you to share applications and provide quick access for customizing the settings of your TAB 4G T701.

Charms bar

Launching the Charms bar

Swipe from the right edge of your TAB 4G T701's touch screen panel, to launch the Charms bar

Inside the Charms bar



Search

This charm allows you to look for files, applications, or programs in your TAB 4G T701.



Share

This charm allows you to share applications via social networking sites or e-mail.



Start

This charm revert the display back to the Start screen. From the Start screen, you can also use this to revert back to a recently opened app.



Devices

This charm allows you to access and share files with the devices attached to your TAB 4G T701 such as an external display or printer.



Settings

This charm allows you to access the PC settings of your TAB 4G T701

Snap feature

The Snap feature displays two apps side-by-side, allowing you to work or switch between apps.

IMPORTANT!

- You can only activate the snap feature in landscape orientation.
- Ensure that your TAB 4G T701's screen resolution is set to 1280x800 pixels or higher before using the Snap feature.

Using Snap

To activate Snap using the touch screen panel of your TAB 4G T701, you can perform the following steps:

1. Launch the app that you wish to snap.
2.. Tap and hold the app's topmost part then drag it to the left or right side of the screen until the snap bar appears.
3. Launch another app.

Connecting to wireless networks

Wi-Fi

Access e-mails, surf the Internet, and share applications via social networking sites using your TAB 4G T701's Wi-Fi connection.

> **IMPORTANT!** The **Airplane mode** disables this feature. Ensure that **Airplane mode** is turned off before enabling the Wi-Fi connection of your TAB 4G T701.

Enabling Wi-Fi

Activate Wi-Fi in your TAB 4G T701 using the following steps on your touch screen panel.

To enable the Wi-Fi:

1. Launch the **Charms** bar.
2. Tap 

then tap.

3. Select an access point from the list of available Wi-Fi connections.
4. Tap **Connect** to start the network connection.

> **NOTE:** You may be prompted to enter a security key to activate the Wi-Fi connection.

5. If you want to enable sharing between your TAB 4G T701 and other wireless-enabled systems, tap **Yes**. Tap **No** if you do not want to enable the sharing function.

Bluetooth

Use Bluetooth to facilitate wireless data transfers with other Bluetooth-enabled devices.

> **IMPORTANT!** The **Airplane mode** disables this feature. Ensure that **Airplane mode** is turned off before enabling the Bluetooth connection of your TAB 4G T701.

Pairing with other Bluetooth-enabled devices

You need to pair your TAB 4G T701 with other Bluetooth-enabled devices to enable data transfers. To do this, use the touch screen panel as follows:

1. Launch the **Charms** bar.
2. Tap

then tap **Change PC settings**.
3. Under **PC Settings,** select **PC and devices > Bluetooth** then move the Bluetooth slider to **On**.



4. Select a device from the list. Compare the passcode on your TAB 4G T701 with the passcode sent to your chosen device. If they are the same, tap **Yes** to successfully pair your TAB 4G T701 with the device.

NOTES:

- For some Bluetooth-enabled devices, you may be prompted to key in the passcode of your TAB 4G T701.
- Ensure that your Bluetooth-enabled devices are discoverable.



Turning your TAB 4G T701 off

You can turn off your TAB 4G T701 by doing either of the following procedures:

- From the **Charms** bar, tap 

then tap

> Shut down to do a normal shutdown.

- From the log-in screen, tap

> Shut down.

- From the desktop mode, tap and hold 

then tap **Shut down or sign out** > **Shut down**.

- If your TAB 4G T701 is unresponsive, press and hold the power button for at least ten (10) seconds until your TAB 4G T701 turns off.

Putting your TAB 4G T701 to sleep

To put your TAB 4G T701 on Sleep mode, press the power button once.

Recovering

Refreshing your TAB 4G T701

Use **Refresh your PC without affecting your files** if you want to refresh your system without losing your current files and apps.

To refresh your TAB 4G T701:

1. From the **Charms** bar, tap 

then tap **Change PC settings**.
2. Under **PC settings**, tap **Update and Recovery** then tap **Recovery**
3. Under **Recovery**, tap

under **Refresh your PC without affecting your files**.

> **IMPORTANT!** Ensure that your TAB 4G T701 is plugged in to a power source before refreshing its system.

Restoring your TAB 4G T701

Use **Remove everything and reinstall Windows** if you want to reset your system to its factory settings.

To restore your TAB 4G T701:

1. From the **Charms** bar, tap 

then tap **Change PC settings**.

2. Under **PC settings**, tap **Update and Recovery** then tap **Recovery**

3. Under **Recovery**, tap

under **Remove everything and reinstall Windows**.

IMPORTANT!

- Ensure that your TAB 4G T701 is plugged in to a power source before resetting its system to its factory settings.
- Back up all your data before performing this option.